

2 Student Diamond Interchange Desk

Assembly Instructions




For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061.

Hardware and Components




Connector Bolt ¼-20 X 23mm P/N: 70867 QTY: 2




Connector Nut ¼-20 x 17mm P/N: 70869 OTY: 2




#10 x 5/8" Wood Screw P/N: 70080 QTY: 20



Hex Key Allen Wrench 3/16" P/N: 77813 QTY: 1






Replacement Hardware Pack:


- 1. 69761 BLA/ZINC-R
 - a. (2) 70867 Connector Bolt ¼-20x23mm
 - b. (2) 70869 Connector Nut 4-20x17mm
 - c. (14) 70080 #10x5/8 Truss Head Phillips Head
 - d. (1) 77813 Hex Key Allen Wrench 3/16"

Assembly Instructions

Step 1: Align the center support with the pre-drills on the top.



Step 2: Position the other legs as shown below, aligning them with the pre-drills.



Step 3: Secure the legs together **loosely** with the connector bolts provided.

Step 4: Fasten the frame assembly to the top using the 5/8" wood screws provided.

Step 5: Tighten the connector bolt using the Allen Key (Hex Key) provided.