

-Apple Back -Apple T-Mold

For assistance in assembling product, missing or damaged parts, or to place an order please contact customer service at 1-800-328-1061. You may also place your order online at




www.smithsystem.com

Form #179942

Page 1 of 2 Rev. 07/2009

UXL P-Tablet Chair Directions

Step 1: Flip the chair upside down and locate the P-Tablet Arm sandwich plate. Look carefully at the sandwich plates and note which side labeled top and bottom as well as which direction the arrow points to indicate 'Front'.



- (B) Locate the piece of the sandwich plate labeled 'Front Top' and slide it under the chair frame.
 - (1) The label on the 'Front Top' plate should be placed as shown below:



(C) Locate the piece of the sandwich plate labeled 'Front Bottom'.

(1) Place this plate on top of the 'Front Top' plate and 'finger' tighten the M8x35mm Nyloc bolts with a 6mm Allen key.




- (2) Be sure that the words 'Front Bottom' are visible on the bottom of the chair. Also be sure that your arrow points toward the Front Arrow Marking on your Chair..
- (D) Place your 3/4" P-Tablet top laminate side down on a clean, dry surface. Place the P-Tablet Arm on the Tablet Top. Locate the (3) top attachment brackets and line them up with the pre-drilled holes. With the holes lined up; attach the brackets to the top with the (12) 3/16" x 5/8" wood screws.





(E) With the sandwich plate 'finger tight'; and the P-Tablet top attached to the Arm., slide the P-Tablet Arm into the sandwich plate until the two small "Alignment dots" are pressed against the Bracket as shown below;



(G) This completes the assembly of your P-Tablet Chair and the product is now ready for use



Page 3 of 3 Rev. 07/2009