


Interchange Activity Table Assembly Instructions




For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061


You may also place your order online at


www.smithsystem.com

Hardware and Components









04117

04118

04119

04121

04122

04123

04124

04125

04126

04129

04132

04151

79807

79807

79808

79808

79808

79808

79805

79805

79806

79508

79806

79805

77510

77511

77508

77510

77511

77505

77506

77508

77508

77508

77509

2

2



67608

67608

67608

67608

67608

67608

67607

67607

67607

67607

67607

67607

42X72

42X90

48X48

48X72

48X90

42 DIA


48 DIA.

60 DIA.

CONTOUR

FLOWER

30X60 BUTCHER





P/N: 70867 – Connector Bolt ¼-20 x 23mm P/N: 70869 – Connector Nut ¼-20 x 17mm (QTY: See Table)

MODEL	LEG SET	BRACE	BRACE QTY	HARDWARE PACK	TOP SIZE
04100	79804	77506	I	67607	24X36
04101	79804	77508	I	67607	24X48
04102	79804	77509	I	67607	24X60
04103	79804	77510	I	67607	24X72
04104	79804	77511	I	67607	24X90
04105	79805	77506	I	67607	30×36
04106	79805	77508	I	67607	30×48
04107	79805	77509	I	67607	30×60
04108	79805	77510	I	67607	30×72
04109	79805	77511	I	67607	30×90
04110	79806	77506	I	67607	36×36
04111	79806	77508	Ţ	67607	36×48
04112	79806	77509	I	67607	36×60
04113	79806	77510	I	67607	36×72
04114	79806	77511	1	67607	36×90
04115	79807	77507	2	67608	42X42
04116	79807	77509	2	67608	42X60


Replacement Hardware Packs:

- 1. 67607 HDWR PK, Inter Act 24, 30, 36
 - a. (2) 77813 3/16" Allen Wrench
 - b. (4) 70867 Connector Bolt ¼-20 x 23mm
 - c. (4) 70869 Connector Nut ¼-20 x 17mm
 - d. (26) 70054 #10x3/4" Wood Screw
- 2. 67608 HDWR PK, Inter Act 42, 48
 - a. (2) 77813 3/16" Allen Wrench
 - b. (8) 70867 Connector Bolt ¼-20 x 23mm
 - c. (8) 70869 Connector Nut ¼-20 x 17mm
 - d. (44) 70054 #10x3/4" Wood Screw


For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061 You may also place your order online at

Assembly Instructions

Step 1: Place the top on a clean, dry surface laminate side down, so that the predrill holes face up. **Step 2a:** Loosely attach the legs to the support brace using (4) connector bolts and (4) connector nuts. (See Picture #1A)



Step 2b: If your table requires a bigger assembly, attach the legs to the braces using (8) Connector Bolts and (8) connector Nuts. (See Picture #1B)




For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061

You may also place your order online at

www.smithsystem.com


Step 3: Align the slots of the Leg Assembly to the pre-drilled holes of the top. Using the $\frac{3}{2}$ " screws provided, attach the leg assembly to the top. (Tip: Stagger the screws in the beginning. For example, Fasten one screws on one of the legs, then another screw on the other leg. Continue to stagger the screws until the assembly is attached to the top using all of the screws.

NOTE: BUTCHER BLOCK TABLES do not have predrilled holes. The top surface of the table will have a noticeably glossier finish than the underside. Center the preassembled frame to the underside of the butcher block top and drive the provided wood screws into the top.



Step 4: Tighten the connector bolts and nuts to the channel, attached in Step 2, using both hex keys provided.

Step 5: Adjust the leg height as needed by loosening the set screw in the leg (use the hex key to loosen). Tighten the set screws. Hand tighten, do not use power tool, to tighten set screw to ensure screw is correctly located in the insert hole.



For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061

You may also place your order online at

www.smithsystem.com

Step 6: If installing casters, unscrew the glides and oval washers from all legs.



For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061

You may also place your order online at

Step 7: Once the glides and oval washers have been removed, screw in the casters to the bottom of the leg caps using the provided wrench. Do **NOT** reuse the oval glides with the casters, as this prevents the casters from being installed properly.





Step 8: Use the help of at least one other person and turn the table over to an upright position.

For Assistance in assembling product, missing or damaged parts, or to place an order, please contact customer service at 800-328-1061 You may also place your order online at

www.smithsystem.com